

L 1 = less-than-one (1) or zero (0)

A = Sample not tested, too long in transit

EST = High colony density preventing accurate count

G = Greater than

O/G = Overgrown with coliform present

B = More than 200 background colonies / 100 ml

D = Sample not tested; no collection date given

T = Sample submitted exceeded 30 hours holding time

<b>Date</b>	<b>Location</b>	<b>Column1</b>	<b>Total coliform</b>	<b>Total E. Coli</b>
<b>29-Apr-20</b>	Sample Station # 1 Behind Hotel		L1	L1
	Sample Station #2 Earl Street near the school		L1	L1
	Sample Station # 3 Marble Bay Road @ Van Anda Ave		L1	L1
	Sample Station # 4 Smelter Road, across from Bob Gordon's		L1	L1
	Sample Station # 5 Sellentin Street @ Sturt Bay Road		L1	L1
	Sample Station # 6 Wall Street Pumphouse		L1	L1
	Sample Station # 7 Copper Queen Street @ Alladin		L1	L1
	Sample Station # 8 Storage Tank		L1	L1
	Pre-treatment raw water		83.6	L1
<b>27-May-20</b>	Sample Station # 1 Behind Hotel		L1	L1
	Sample Station #2 Earl Street near the school		L1	L1
	Sample Station # 3 Marble Bay Road @ Van Anda Ave		L1	L1
	Sample Station # 4 Smelter Road, across from Bob Gordon's		L1	L1
	Sample Station # 5 Sellentin Street @ Sturt Bay Road		L1	L1
	Sample Station # 6 Wall Street Pumphouse		L1	L1
	Sample Station # 7 Copper Queen Street @ Alladin		L1	L1
	Sample Station # 8 Storage Tank		L1	L1
	Pre-treatment raw water		55.6	L1
<b>30-Jun-20</b>	Due to ferry shut downs - samples could not get to lab in a timely manner			
<b>22-Jul-20</b>	Sample Station # 1 Behind Hotel		L1	L1
	Sample Station #2 Earl Street near the school		L1	L1
	Sample Station # 3 Marble Bay Road @ Van Anda Ave		L1	L1
	Sample Station # 4 Smelter Road, across from Bob Gordon's		L1	L1
	Sample Station # 5 Sellentin Street @ Sturt Bay Road		L1	L1
	Sample Station # 6 Wall Street Pumphouse		L1	L1
	Sample Station # 7 Copper Queen Street @ Alladin		L1	L1
	Sample Station # 8 Storage Tank		L1	L1
	Pre-treatment raw water		1986.3	L1