

L 1 = less-than-one (1) or zero (0)

A = Sample not tested, too long in transit

EST = High colony density preventing accurate count

G = Greater than

O/G = Overgrown with coliform present

B = More than 200 background colonies / 100 ml

D = Sample not tested; no collection date given

T = Sample submitted exceeded 30 hours holding time

Date	Location	Total coliform	Total E. Coli
29-Apr-20	Sample Station # 1 Behind Hotel	L1	L1
	Sample Station #2 Earl Street near the school	L1	L1
	Sample Station # 3 Marble Bay Road @ Van Anda Ave	L1	L1
	Sample Station # 4 Smelter Road, across from Bob Gordon's	L1	L1
	Sample Station # 5 Sellentin Street @ Sturt Bay Road	L1	L1
	Sample Station # 6 Wall Street Pumphouse	L1	L1
	Sample Station # 7 Copper Queen Street @ Alladin	L1	L1
	Sample Station # 8 Storage Tank	L1	L1
	Pre-treatment raw water	83.6	L1
27-May-20	Sample Station # 1 Behind Hotel	L1	L1
	Sample Station #2 Earl Street near the school	L1	L1
	Sample Station # 3 Marble Bay Road @ Van Anda Ave	L1	L1
	Sample Station # 4 Smelter Road, across from Bob Gordon's	L1	L1
	Sample Station # 5 Sellentin Street @ Sturt Bay Road	L1	L1
	Sample Station # 6 Wall Street Pumphouse	L1	L1
	Sample Station # 7 Copper Queen Street @ Alladin	L1	L1
	Sample Station # 8 Storage Tank	L1	L1
	Pre-treatment raw water	55.6	L1
30-Jun-20	Due to ferry shut downs - samples could not get to lab in a timely manner		
22-Jul-20	Sample Station # 1 Behind Hotel	L1	L1
	Sample Station #2 Earl Street near the school	L1	L1
	Sample Station # 3 Marble Bay Road @ Van Anda Ave	L1	L1
	Sample Station # 4 Smelter Road, across from Bob Gordon's	L1	L1
	Sample Station # 5 Sellentin Street @ Sturt Bay Road	L1	L1
	Sample Station # 6 Wall Street Pumphouse	L1	L1
	Sample Station # 7 Copper Queen Street @ Alladin	L1	L1
	Sample Station # 8 Storage Tank	L1	L1
	Pre-treatment raw water	1986.3	L1
01-Sep-20	Sample Station # 1 Behind Hotel	L1	L1
	Sample Station #2 Earl Street near the school	L1	L1
	Sample Station # 3 Marble Bay Road @ Van Anda Ave	L1	L1
	Sample Station # 4 Smelter Road, across from Bob Gordon's	L1	L1
	Sample Station # 5 Sellentin Street @ Sturt Bay Road	L1	L1
	Sample Station # 6 Wall Street Pumphouse	L1	L1
	Sample Station # 7 Copper Queen Street @ Alladin	L1	L1
	Sample Station # 8 Storage Tank	L1	L1
	Pre-treatment raw water	2419.2	L1